

TABLEAU DE CONVERSION

| Mesures en pouce (") | Mesures en centimètres (cm) |
|-------------------------|--------------------------------|
| Netbook | |
| 7,0" - 8,9" | 23 |
| 7,0" - 9,0" | 23 |
| 8,9" - 10,2" | 26 |
| 10,2" | 26 |
| 10,2" - 12,1" | 31 |
| 12,1" | 31 |
| Notebook | |
| 13,0" | 34 |
| 13,1" | 34 |
| 13,3" | 34 |
| 15,4" | 40 |
| 15,6" | 40 |
| 16,0" | 41 |
| 16,0" - 17,0" | 44 |
| 17,0" | 44 |
| 17,3" | 44 |
| 18,4" | 47 |
| 18,4" - 19,0" | 49 |
| 19,0" | 49 |
| 20,1" | 51 |

1 pouce = 2,54 centimètres