

00055102 Hama Mobile MediaSafe VSV20

Firmware-Update, für Version 1.1.3

1. Überprüfen Sie die Version der Firmware im Menü **OPTIONEN**. Steht unter **FIRMWARE VERSION** der Wert **7F-1.1.3** wird dieses Update nicht benötigt !
2. Nachdem Sie die Firmware Version 1.1.3 geladen haben, entpacken Sie diese auf Ihrem Mobile MediaSafe.
3. Entfernen Sie den VSV nun von Ihrem Computer.
4. Wählen Sie in dem Menü des VSV die Datei **FR7FG113.MMV** und drücken Sie auf **OK** um diese zu starten.
5. Drücken Sie nun nochmals **OK** um das Firmware Update zu starten.

Firmware-Update, for Version 1.1.3

1. Please check the firmware version of your VSV20 under **OPTIONS**. If you can find there **FIRMWARE VERSION** with the value **7F-1.1.3** , there is no need to perform this update!
2. After you have loaded the Firmware version 1.1.3, please extract the file on your Mobile MediaSafe.
3. Afterwards, disconnect the VSV from your computer.
4. Now select the file **FR7FG113.MMV** and execute it directly.
5. Now press again the **OK** button to perform the update.